


TABPB078

Flat Surface Tablet Mount with Push Button Universal Holder



- Quick release push button holder fits any 7"-12" tablet even with casing
- Suction mount with polyurethane adhesive provides a strong mounting base while leaving no sticky residue
- Compatible with iPad, iPad, iPad 3 & 4, Nexus 7, Nexus 10, Samsung Galaxy Note 10.1, Galaxy Tab 7" / 8.9" / 10", Amazon Kindle Fire, Motorola Xoom, HTC Flyer / EVO View 4G, ASUS Transformer Prime, EeePad Transformer, Acer Iconia, Toshiba Thrive, Lenovo IdeaPad, Blackberry Playbook, HP TouchPad and more...









- ◆ Quick release push button holder fits any 7" – 12" tablet even with casing
- ◆ Suction mount with polyurethane adhesive provides a strong mounting base while leaving no sticky residue
- ◆ Compatible with iPad, iPad 2, iPad Mini, Nexus 7, Nexus 10, Samsung Galaxy Note 10.1, Galaxy Tab 7" / 8.9" / 10", Amazon Kindle Fire, Motorola Xoom, HTC Flyer / EVO View 4G, ASUS Transformer Prime, EeePad Transformer, Acer Iconia, Toshiba Thrive, Lenovo IdeaPad, Blackberry Playbook, HP TouchPad and more



Suitable to mount on most desktops, dashboards, windows, walls, airplane seat trays, cabinets and more surfaces.



Mount it just the way you like!

Universal Tablet Push Button Holder



Universal Tablet Push Button Holder allows a maximum extension up to 8.3" (211mm), and a minimum grip of 6.0" (152mm).

*All pictures are for illustration purposes only.



TABPB078

Flat Surface Tablet Mount with Push Button Universal Holder



Universal Tablet Push Button Holder allows a maximum extension up to 8.3" and a minimum grip of 6.0"(152mm)